

DecaPlot Procedure - Extracts:

(Refer Quick Start Guide & Manuals for complete details)

1. Click DecaPlot Control Panel icon
2. Click any where on Welcome Screen
3. If Current Project displayed is not blank, click Export Project Button, select Export Drive & click OK.
4. Copy your staad std & anl file (select files, mouse right click & then copy).
5. Click Select Design & Drawing Project Button
6. Right click mouse & click Paste any where in the white window.
7. Press Open Button
8. Click combo smiley face
9. Click any where on Welcome Screen
10. Click Extract (second column on Menu Bar)
11. Click Extract R.C.C. Frame Details
12. Select Tabulator option & click OK button
13. Click OK button on status report
14. Click OK on successful extraction message
15. To view column design results:
 - a. Click staad column design results (in extract column)
16. To view beam column design results:
 - a. Click staad beam design results (in extract column)
17. To get drawing of column design results:
 - a. Click graphical column results
 - b. Specify parameters like drawing scale etc. & press ok
 - c. Press ok when drawing completion message appears.
 - d. The autocad drawing will be made automatically on the screen
18. To get drawing of beam design results:
 - a. Click graphical beam results
 - b. Select level & press ok.
 - c. Specify parameters like drawing scale etc. & press ok
 - d. Press ok when drawing completion message appears.
 - e. The autocad drawing will be made automatically on the screen